


Box Contents

Contenido de la caja

Contenu de la boîte

Contenuti della confezione

Lieferumfang

A 	B  24" / 61 cm	C (2)  36.2" / 92 cm
D1 (2)  D1= 27.95" / 71 cm	D2 (2)  D2= 31.88" / 81 cm	E  13.8" / 35 cm
F (9) 	G (4) 	H (4) 
I  Tom 1 8" / 20 cm	J  Tom 2 10" / 25 cm	K  Tom 3 12" / 30 cm
L  Tom 4 14" / 36 cm	M  Snare 14" / 36 cm	N  Hi-Hat (Top) 14" / 36 cm
O (3)  Crash 14" / 36 cm	P  Ride 16" / 41 cm	Q  Kick 20" / 51 cm

Box Contents

Contenido de la caja

Contenu de la boîte

Contenuti della confezione

Lieferumfang

R 	S 	T 
U 	V 	W 
X 	Y (4) 	Z 
AA 	BB 	CC (16) 
DD 	EE (2) 